

GPI Board (Actions)



The information is relevant for version [2.9.34](#) and later.

Description of [GPI Board](#) Actions.

Set pin

Sets the output status for the selected pin.

Parameters

- **Param1** - pin number (starts with 1).
- **Param2** - new pin status:
 - 0, off or false - disable
 - 1, on or true - enable
 - other values - no changes

Pulse pin

Sends a pulse of the specified duration to the pin output.

Parameters

- **Param1**-

Trigger Handler

Launches the action handlers (pins) when an input signal is detected.

Parameters

- **Param1** pin number (starts with 1).
- **Param2** - new pin status:
 - 0, off or false - disable
 - 1, on or true - enable
 - other values - no changes

Do Command

Perform a command that is typical for a particular type of hardware.

Parameters

- **Param1** - command name:
 - sGPI for Louth decoder
 - set for Ember+

For Louth decoder (Param1=sGPI)

- **Param2** - Key
- **Param3** - ID
- **Param4** - Segment
- **Param5** - Title
- **Param6** - on_air

For Ember+ (Param1=set)

- **Param2** - Pin number
- **Param3** - Value
- **Param4** - not used
- **Param5** - not used
- **Param6** - not used

From:

<https://wiki.skylark.tv/> - **wiki.skylark.tv**

Permanent link:

https://wiki.skylark.tv/api/actions/gpi_board

Last update: **2023/06/02 07:01**

